Remote Control Guide

Western Iowa NETWORKS

TV, AUD, DVD, VCR, STB
Use one remote to control multiple devices.

SETUP
Use for programming sequences of devices controlled by the remote.

REPLAY
Skip backwards 10 seconds while watching a recording or while watching live TV.

REWIND
Rewind through parts of a recording.

PLAY
Press to watch a recording or control another device

STOP
Press to stop watching a recording or to stop a recording that is in progress.

MENU
Displays applications including the configuration menu.

GUIDE
Opens the Interactive Program Guide.

DAY+/-
Jump one day ahead or back in the Interactive Program Guide.

RED, GREEN, YELLOW, BLUE
Access additional features on your set-top box.

VOL +/-
Raise or lower the volume.

MUTE
Turn the sound off or on.

NUMBER KEYS (0-9)
Directly select a channel.

INPUT
In TV control mode, would change the input of the device you are controlling.

POWER
Turn on/off a selected device.

LIVE
Return to watching live TV.

LIST*
Displays a list of recorded shows on your PVR/DVR set-top box

SKIP FORWARD
Skip forward 30 seconds while watching a recording.

FAST FORWARD
Fast forward through parts of a recording.

RECORD
Press to record a show.

INFO
Display the current channel and program information. Press again for more detail.

PAUSE
Pause what you are currently watching.

ARROW KEYS/OK
Navigate onscreen choices.

EXIT
Exit the current screen.

PAGE+/-
Page up or down in menu screens and Interactive Program Guide.

CHANNEL +/-
Changes to the next higher or lower channel.

LAST
Recall the last channel you were watching.

ON DEMAND*
Access video on demand services.

FAV
View your favorite channels.

**If available.*

Support (888) 508-2WIN | www.westianet.com