

# DVR User Guide



## LIST

Press to see your list of recorded programs. Press it again to see what is scheduled to be recorded.

## LIVE

Press to return to the current part of a live broadcast.

## SKIP FORWARD

Skip forward 30 seconds while watching a recording.

## REPLAY

Skip backwards 10 seconds while watching a recording or while watching live TV.

## FORWARD

Forward through parts of a recording.

## PLAY

Begin watching a recording.

## RECORD

Press to record a show.

## PAUSE

Pause what you are currently watching.

## STOP

Press to stop watching a recording or to stop a recording that is in progress.

## REWIND

Rewind through parts of a recording.

## GUIDE

Access the interactive program guide.

## ARROW

Use arrows to navigate and select on screen choices.



Support (888) 508-2WIN

[www.westianet.com](http://www.westianet.com)