

Programming Remote For Your Set Top Box



IS Set Top Box



1. Press **STB**.
2. Hold **SETUP** until the STB button flashes twice.
3. Enter "1-3-7-6". The STB button should flash twice.

Amino Set Top Box



1. Press **STB**.
2. Hold **SETUP** and "1" simultaneously until the STB button flashes twice.