

DVR User Guide



LIST

Press to see your list of recorded programs. Press it again to see what is scheduled to be recorded.

LIVE

Press to return to the current part of a live broadcast.

SKIP FORWARD

Skip forward 30 seconds while watching a recording.

REPLAY

Skip backward 10 seconds while watching a recording or while watching live TV.

FORWARD

Forward through parts of a recording.

PLAY

Begin watching a recording.

RECORD

Press to record a show.

PAUSE

Pause what you are currently watching.

STOP

Press to stop watching a recording or to stop a recording that is in progress.

REWIND

Rewind through parts of a recording.

GUIDE

Access the interactive program guide.

ARROW

Use arrows to navigate and select on screen choices.



Support (888) 508-2WIN



www.westianet.com