

Programming Remote For Your TV



1. Make sure the TV is on.
2. Press **TV**, it will blink once.
3. Press and hold **SETUP**, the TV key will blink twice.
4. Press **9-9-1**, the TV key will blink once.
5. Press and release the **CH+** key continuously, then stop when the TV turns off.
6. Press **SETUP** to save code.



Support (888) 508-2WIN



www.westianet.com